

IMPORTANT INFORMATION

TECHNICAL BULLETIN

External Components Required for Installation of WarmCair DW Series II

- Condensate pump.
- 2 x AAV's
- Sealed system kit (filling loop, PRV, expansion vessel)
- 2-channel programmer
- Wiring centre (enough terminals for S-plan wiring)
- DHW cylinder with coil suitable for operating under pressure.
- Magnetic filter (if any ferrous metal in system, including radiators, steel cylinder coil, etc)

Ancillaries for Installation of WarmCair DW Series II (available from Johnson & Starley Ltd)

- **Easysafe Flue Components (required)**
See price list
- **Base Duct (optional)**
WBX10W (C102DW)
WBX16W (C162DW)
WB20W (C202DW)
Base duct for C25DW Not available.
- **Top Closure Kit (optional)**
TC10W (C102DW)
TC16W (C162DW)
Top closure not available for C202DW or C25DW
- **Slot Fix Kit (optional)**
TS10W (slot fix panel C102DW)
TSG10W (slot fix panel with grille C102DW)
TS16W (slot fix panel for C162DW)
TSG16W (slot fix panel with grille for C162DW)
Slot fix panels not available for C202DW or C25DW
- **Rear Rising Duct (optional)**
ER102W (rear riser for C102DW)
ER102WR (rear riser extended for C102DW)
Rear riser not available for C162DW, C202DW & C25DW
- **CleanFlow electrostatic filter (optional)**
CF10W (cleanflow for C102DW)
CF16W (cleanflow for C162DW)
CF20W (cleanflow for C202DW)
Cleanflow not available for C25DW
- **Return Air Kit (under development)**

TECHNICAL BULLETIN